




Chicago 3 Way Workstation

Leg And Beam Assembly And Timber Top Attachment Instructions

	M6 x 40 12pcs		M5 x 20 24pcs
	M8 x 20 6pcs		

*** For Timber Top Fitment, First Centre Top And Ensure That The Correct Length Screw Is Used ***

