



A3 Backrest Height Adjustment




Hold the two sides of the backrest handle, one could adjust the backrest up or down. The backrest would be returned back to the lowest when pushed to the top. There is 1.57" adjustable.

B1 Armrest Height Adjustment




Press the two-side armrest height adjustment buttons to raise or lower the armrests. There are 8 positions with 3.15" range.

B2 Arm Pad Angle Adjustment




Arm Pad Angle Adjustment: A range of 9° can be achieved by swiveling the arm pads inwards, or swiveling the arm pads outwards to achieve another 15°.

B3 Arm Pad Width Adjustment




Width Adjustment: hold and push the arm pads outwards or inwards into a desired width of the arms. There are 1.57" range adjustment totally.

C1 Seat Height Adjustment




Pull up the single rod control lever and hold it while raising or lowering the seat to change the seat height. When the lever is released, the seat height is locked.

C2 Seat Depth Adjustment




Push the single rod control lever forward to adjust the seat depth (The approximate range is 1.97"). Return the lever to the original middle position, the position will be fixed.

A4 Lumbar Support Height Adjustment




A. The height of lumbar support can also be adjusted by adjusting the backrest height.
B. Suitable height of the lumbar support would bring more comfort for one's waist.

B4 Arm Pad Forward and Backward Adjustment




Forward and Backward Adjustment: Push the arm pads forward or backward to a desired position. The range for it is about 1.57".

C1 Seat Height Adjustment





Since an incorrect seat height contributes to back's fatigue, it is recommended that the angle of knees is slightly less than 90° and feet are level with the floor.

C2 Seat Depth Adjustment



Ideal depth is achieved when the upper legs are on the seat, the lumbar area is in touch with the backrest of the chair, and the back of knees do not touch the edge of seat cushion.





Parts List


① CASTER × 5	④ ARMREST × 2
② BASE × 1	⑤ SEAT CUSHION × 1
③ GAS LIFT × 1	⑥ BACK CUSHION × 1
Bolts & Washers ⑦ M8 × 25mm FOR ARMREST ⑧ M8 × 22mm FOR BACKREST	
ALLEN WRENCH	

Product Assembly Instruction


STEP 1




STEP 2



STEP 3




STEP 4




Function Controls

- Backrest Height Adjustment Handle
- Armrest Height Adjustment Button
- Single Rod Control Lever for Seat Slide, Seat Height and Back Angle Adjustment
- Backrest Tilt Tension Adjustment Handle




Function Adjustments

- Headrest Height, Angle, Forward & Backward Adjustment
- Backrest Height Adjustment
- Backrest Tilt Angle and Tilt Tension Adjustment
- Arm Pad Angle Adjustment
- Arm Pad Width Adjustment
- Arm Pad Forward and Backward Adjustment
- Armrest Height Adjustment
- Seat Height and Depth Adjustment




A1 Headrest Height Adjustment




Hold the handle of headrest to adjust the height of it, there are 6 position with 40mm adjustable

A2 Headrest Angle Adjustment




Hold the headrest cushion to adjust the angle of it, there is 30° adjustable.

A1 Headrest Height Adjustment




The most suitable height could be achieved when one's scruff is fully supported by the headrest.

A2 Headrest Angle Adjustment




The best angle could be reached when one could move the neck naturally.

A1 Backrest Tilt Angle Adjustment




Pull the single rod control lever completely backward and lean against back until a desired angle is achieved, and then return the lever to the original middle position to lock at an ideal angle. There are 4 positions with 25° range.

A1 Backrest Tilt Angle Adjustment




The proper backrest angle can reduce the pressure on the spine.

A2 Backrest Quick or Slight Tilt Tension Adjustment



Pull the Lever outwards, open the Tilt Tension Adjustment Handle, and turn it forward or backward into a desired tension for quick tilt tension adjustment or close the handle and turn it forward or backward for slight tilt tension adjustment, and then close the handle and push the lever inwards to the original position to fix it.

A2 Backrest Quick or Slight Tilt Tension Adjustment



The synchro mechanism is ergonomically designed to enhance comfort and reduce strain. The back-to-seat adjustment/tilt is 3:1 ratio.